
NewStar user's Manual

LCD Monitor Arm FPMA-W300





www.NewStar.nl Phone: + 31 (0) 23 547 88 88

LCD Monitor Arm

Fitting Check-List


01 Small Screw 8pcs

02 Long Screw 4pcs


03 Cable Holder 1pcs

Cable Tie 04 3pcs


Wrench 05 1pcs




Arm Operation




Assembly Guide a.




Secure bottom plate firmly to the wall with four expansion screws (not supplied).





Make sure of direction correct during assembly. (as illustrated)




Use cable holder 03 & cable tie 04 supplied to finish cable management.

Caution:

- ☐ Standard product fit VESA interface 75*75mm & 100*100mm.
- ☐ Before assembling, please check assembly guide thoroughly to avoid any mistake.
- ☐ Weight capacity for 1-6kgs LCD monitors.
- ☐ Standard products include several small parts, keep out of children when assemble this product and prevent children from swallowing them.
- □ Do not put your fingers on the joint during arm moving to prevent from FPMA-W300 clipping.

Adjusting Universal Joint Tension

When assembling the arm with monitors of differing weights, you may find that the tension of the universal joint needs to be adjusted to ease movement or to maintain the desired monitor position. If so, adjust as follows:



- a. Remove the four plastic universal joint covers
- b. Find the nylon nut (not the screw head) and use the included wrench to adjust the tension.
- c. Use one hand to support the monitor and adjust the tension of the universal joint.
 - ☐ Clockwise : more tension
- □□□□□ Counterclockwise : less tension
- d. When the desired tension is achieved, replace the four plastic covers.

Caution:

- ☐ Support the monitor during the adjustment procedure.
- ☐ Only adjust the nylon nut (not the screw head).
- \square Do not disassemble the universal joint .